

Digiprog 3 Adapter List

NO.	Adapter
ST01	8 Pin SOIC Clip
ST04	8 Pin Dill Chip Clip
ST06	BMW OBD Diagnostic Plug
ST07	BMW Compact SW7
ST08	Mercedes Benz C Class VDO 1993/1995 ST08 ST09 ST15 ST18
ST09	VW Golf 3 MM Cluster Diagnostic
ST10	Mercedes Benz OBD Diagnostic Plug
ST11	Mercedes Benz S Class Cluster Diagnostic
ST12	Mercedes Sprinter Kienzle Diagnostic plug
ST13	Digiprog Power Lead
ST14	Audi A6 Diag 1994/1996 & ST17 Audi A6 Diag 1994/1996
ST15 ST18	VW Golf Mk3 VDO Cluster Diagnostic
ST16	OBD II Diagnostic
ST19	Mercedes Sprinter VDO Cluster diagnostic
ST20	BMW 5/7 Series Cluster Diagnostic
ST21	Toyota Avensis Cluster Diagnostic
ST22	Peugeot 306 VDO Cluster Diagnostic
ST23	Jaguar XJ6 11DU 90/91/93/95
ST24	Data lead for ST16

ST25	Ford Scorpio Cluster Diagnostic
ST26	BMW 3 Series Compact SW9/10
ST27	Ford Focus
ST28	Peugeot 206 Jeager
ST29	Ford Feista Mk 3 & 4 up to year 2000
ST30	Smart car BSI
ST31	Peugeot 406 VDO Cluster Dianostic
ST32	Fiat Multipla
ST3	3 Alfa 156 HC11
ST34	Alfa 145/146 ST
ST35	HC11 lead this is used on sevral applications
ST36	Alfa
ST37	Jaguar XK8
ST38	Ford Cougar
ST3	9 Peugeot 806 Citroen Synergy, Fiat ScudoCable Title
ST41	Audi MM Dash cluster lead
ST42	This lead has sevral applications
ST45	Chrysler Grand Cherokee 1999/2000 Cluster Dignostic
ST46	Peugeot 406 Jeager
ST47	This lead has sevral applications
ST49	Mercedes W203 Diagnostic

ST50	Mercedes A Class HC 12 & Vaneo
ST51	HC12 Micro lead
ST55	Jaguar X Type
ST60	W211 & W203 Cluster Diagnostic
	POWER 12V DC
ST-bmw	
	Alternate cable