CGDI MB Adds Old Benz Kline W202 W208 W210 Key via OBD

CGDI MB adds Mercedes Benz old K-line vehicle key programming. Here's the guide on adding new keys to w202 w208 w210 kline MB 38pin car from 1997 to 1998 via OBD.(Original car key)

New key to be programmed

Step 1: Calculate Password

Connect CGDI Prog with laptop and vehicle

Open CGDI MB software

Go to EIS->Read EIS data

Select Computer Password-> Copy key with key-> Collect data

Follow 7 steps below to collect data

1.Insert original key into EIS and press OK

This is a k-line EIS, the operation is different from the ordinary EIS.

2.Insert key into CGDI MB and wait for collection

3.Insert the car key into EIS 10s and remove

Make sure to twise the key to ON position and turn on insturment. If failed to do this, pull ouit the ey

and try again. Press OK to continue.

4.Insert the key into EIS

5. Remove the key for 5s and then insert the key into EIS
6. Insert the key into CGDI MB
7. Save the generated files

8.Save the file successfully. Upload the data to calculate password.

Upload data successfully. Press Query Results to calculate pass--done

Copy and paste the pass to EIS Key password area and then save it

Select Generate EE->V051-> Load EIS file

Upload EIS file just saved-->Press Generate Key File-->The key file was generated successfully

Go to Read/Write Key->IR --->
read the key/chip

Then Open/Write

Smart key choose 41 format, common key and BE key cchoose 51 format.

Select a key file and write it.

Write key success.

Test the new key. Works good.

Done!